




New VGA switch boxes




Both Green lights on will project the computer screen on the projector and computer screen.



Orange light on 1 and Green light on 2 will show the document camera briefly on the computer screen and the computer image on the projector. If the document camera isn't on, the computer screen will not show anything. The computer screen goes into power save mode shortly after showing the document camera because it isn't recognizing the input.



Both Orange lights on will project the document camera on both the computer screen and the projector screen. If the document camera is not on, the computer will not project anything to the computer screen or projector. The computer screen goes into power save mode shortly after showing the document camera because it isn't recognizing the input.



Green light on 1 and Orange light on 2 will show the document camera on the projector screen and the computer image on the computer screen. If the document camera isn't on, the projector screen will not show anything.